


DVD/VCR Player connection to Television

1. Attach Cables as shown



2. Press the TV button and then the Input button on the remote to put the TV in video mode so that it's ready to show the VHS tape from the DVD/VCR player. When you're in video mode, you will see it on the TV screen as shown on the image below.

